

**IN THE SPECIFICATION**

Please amend numbered paragraph [0039] as follows.

[0039] Vacuum pump system 58 can, for example, include a turbo-molecular vacuum pump (TMP) capable of a pumping speed up to 5000 liters per second (and greater) and a gate valve for throttling the chamber pressure. In conventional plasma processing devices utilized for dry plasma etch, a 1000 to 3000 liter per second TMP is generally employed. TMPs are useful for low pressure processing, typically less than 50 mTorr. At higher pressures, the TMP pumping speed falls off dramatically. For high pressure processing (i.e., greater than 100 mTorr), a mechanical booster pump and dry roughing pump can be used. Furthermore, a device for monitoring chamber pressure (not shown) is coupled to the process chamber ~~46~~ 10. The pressure measuring device can be, for example, a Type 628B Baratron absolute capacitance manometer commercially available from MKS Instruments, Inc. (Andover, MA).